

## 2-Way Lamp Module PLM21

### INSTALLATION AND OPERATING INSTRUCTIONS

1. Set the black Unit Code dial on the front of the Module to the desired number between 1 and 16.
2. Set the red Housecode dial to the same letter as your X-10 PRO Controllers or the same letter as used with your 2-Way Computer Interface (CK11A) and ActiveHome software.
3. Make sure the lamp (incandescent only) you want to control is turned on, and unplug it from its outlet.
4. Plug the lamp into the module.
5. Plug the module into the AC outlet.

To turn the module on/off, press the number corresponding to its Unit Code on any X-10 Controller (i.e. PHC01), then press ON/OFF.

Note: the PLM21 is a 2-Way module so you can poll it (ask it for its status) from the 2-Way Computer Interface and ActiveHome software. ActiveHome will ask the PLM21 for its status and the module will report back to indicate whether it is on or off. The ActiveHome software will then update the graphics on your computer monitor screen to show the status of the module. See your owner's manual for the ActiveHome system for more information.

### X-10 PRO LIMITED 2-YEAR WARRANTY

X-10 PRO warrants X-10 PRO products to be free from defective material and workmanship for a period of two (2) years from the original date of purchase at retail. X-10 PRO agrees to repair or replace, at its sole discretion, a defective X-10 PRO product if returned within the warranty period and with proof of purchase. If service is required under this warranty please return your defective product to the dealer you purchased it from.



PLM21-9/98