



Registering the Security Remote with the X-10 PRO Security Console

- Set the codewheel on the Security Remote to the same house code as the Security System.
Note: The house code for the Security System is downloaded by the security installation firm. The default is 'A', when using the PRO2000 Security Console.
- Fit four AAA Alkaline batteries in the battery compartment in the back of the remote.
- Set the slider switch on the Security Console to INSTALL.
- Press ARM. The console chimes once to confirm that the remote has been registered.
- Return the console slider switch to the RUN1 or RUN2 position.
Note: If the remote did not register, remove the label on the front and use a pencil or other pointed object to press the small CODE button to generate a new random code. Press ARM again to install the remote.

Testing the Security Remote

- Set the slider switch on the security console to RUN1 or RUN2.
- Press ARM AWAY on the remote. The console chimes once to confirm and the ARM indicator lights.
- Press SECURITY LIGHT ON and OFF to control a light connected to a lamp module with codewheels set to default A13, when using the PRO2000 (or other code downloaded by the security installation firm).
Note: As with all RF transmitter devices; electrical fields, metal doors/wall studs and appliances can cause interference that can decrease the strength of the transmitted signal. Re-orienting the transmitter or receiver console may increase your ability to send and receive the necessary signals.